



8



9

### Special sleep time setting:

Note: The following sleep time, set up only need to scan the bar code can be set accordingly.



5Min



10Min



30Min



None

### Buzzer



\*Sound ON



Sound OFF



Low



\*Mid



High

### Custom prefix Prefix Settings



Add prefix



Delete Prefix



Modify prefix



Save prefix settings

Scan "Modify Prefix" and scan data code, user can modify the prefix content  
Note: When Prefix Settings OK, must scan Save Prefix Setting to finish the setting

### Custom prefix Suffix Setting



Add Suffix



\*Delete Suffix



Modify Suffix

Scan "Modify Suffix" and scan data code, user can modify the suffix content

### USB Country Keyboard types



\*USA



Czech



German



6



7



Italy



8



9



Spain



A



B



1



C



D



3



E



F



5



Save



4

### Number Appendix



0



1



2



E



4



Save

Cancel one data before read

## Introduction

Under data uploading mode, the purple indicator keeps flashing when uploading data; Under inventory mode, the red indicator keeps on when uploading data; Under Over-distance storage mode, the red indicator keeps flashing when uploading data

Real-time checking for battery, it cannot work when the battery power is too low. And it makes "beep" sound every 10 seconds, after 5 "beep" sounds, the scanner turns off automatically.

When the scanner is in over transmission distance condition, connecting the scanner to the receiver, press the trigger button, the data will be uploaded to the receiver. But the data will not uploaded to the cell phone. When the scanner is in inventory mode, the scanner will not into over-distance storage mode.



Factory Default



RF Setting



Bluetooth Mode

Note : If return to Factory Default, please scan "Factory Default", "RF Setting", "Bluetooth Mode" in order



Over-distance storage mode ON



Over-distance storage mode OFF

### One scanner to one receiver (one to one)

Step 1: connect the receiver to Host device

Step 2: Scan below QR code or the "Disconnect" OR code in the receiver.



Step 3: Scan the "Connect" OR code in the receiver, wait seconds to complete the pairing.

Note: Flashing Blue Led indicates pairing succeed

## Multiple Scanners Pair With One Receiver

Step 1: The first scanner finish pairing by one to one step

Step 2: To use paired scanner scan "one pair with more mode"



Step 3: Scanner finish pairing by one to one step.  
Step 4: if quit multiple scanner pair with one receiver mode, to scan this code.



Note: Scan this bar code, the receiver needs to re-plug will exit multi-scanners paired with a receiver mode

## Connect to mobile device

Open Android or IOS devices bluetooth and search for bluetooth devices after scan this barcode, then connect to the bluetooth device.



### Keyboard ON or OFF in IOS mode



Note: In IOS mode, if the keyboard on, scan this code the keyboard will off. If the keyboard off, scan this code the keyboard will on

## Inventory Mode



Enter Inventory mode



Quit Inventory mode



Upload all datas



Upload New datas



Upload Statistic datas

## Scan Mode



Manual



Successive scanning



Clear all datas



No Illumination

## Sleep Time Setting

Setting steps:

1. Scan "Enter Sleep Time Setting"

2. Set sleep time parameter (Unit: minutes)

Example: Set sleep time 10 minutes, scan the sleep time number "0", "1" and "0" in order

Note: The sleep time is 1 to 999 minutes, consisting of three digits, followed by one hundred, ten, a bit, each set of sleep time must be three-digits number

3. Scan "Save Sleep Time Parameter"

Note: After setting the sleep time parameter, the parameter must be saved. If set error, the scanner will give a alarm and you need to set again



Enter Sleep Time Setting



Save Sleep Time Parameter

### Sleep Time Number Code:



0



1



2



3



4



5



6



7



Auto-Conduction

## Suffix Settings

Trigger command mode



\*Enter



Enter and Line



TAB



None

## Illumination and Aim Settings



\*Normal Illumination



Continue lights Mode